

# SPARE PARTS LIST

MODEL NO. 6280D

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	125102-2	SPEED CHANGE LEVER ASS'Y	1	
002	183824-0	HOUSING SET INC. 15	1	
003	860447-8	NAME PLATE 6280D	1	
004	266130-9	TAPPING SCREW BIND PT 3X16	9	
005	232182-2	LEAF SPRING	1	
006	417283-9	F/R CHANGE LEVER	1	
007	650556-9	SWITCH C3NA-1-M1	1	
008	643909-9	BATTERY HOLDER	1	
009	251468-5	- FLAT HEAD SCREW M6X22	1	
010	763185-0	KEYLESS DRILL CHUCK 10	1	
011	125237-9	GEAR ASS'Y	1	
012	629819-4	DC MOTOR	1	
013	911003-8	PAN HEAD SCREW M3X6	2	
014	819001-5	MAKITA LABEL	1	
015	183824-0	HOUSING SET INC. 2	1	
A01	414938-7	BATTERY COVER	2	
A02	***DC1414	DC1414 BATTERY CHARGER	1	
A03	784636-0	+ - BIT 2-65	1	
A04	824581-8	PLASTIC CARRYING CASE	1	
A05	193985-8	BATTERY PA14 SET	2	
A06	345261-8	HOOK PLATE	2	
A07	417926-3	STRAP G0970200500	1	
A08	192752-8	ML140 RECHARGEABLE FLASHLIGHT	1	

# SERVICE DRAWING

MODEL NO. 6280D

