

SPARE PARTS LIST

MODEL NO. DTW280

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	187821-8	HOUSING SET INC. 38	1	
002	815N04-1	DTW280 NAME PLATE	1	
003	266130-9	TAPPING SCREW BIND PT 3X16	8	
004	419041-9	F/R CHANGE LEVER	1	
005	650673-5	SWITCH C3JW-1A	1	
006	268184-2	PIN 1.5	1	
007	263036-2	RUBBER PIN 5	1	
008	424568-6	BUMPER	1	
009	454851-7	HAMMER CASE COVER	1	
010	142388-3	HAMMER CASE COMPLETE	1	
011	261154-0	NYLON WASHER 28	1	
012	231907-1	RING SPRING 10	1	
015	135617-1	ANVIL E ASS'Y INC. 12	1	
016	326384-1	HAMMER	1	
017	216001-0	STEEL BALL 3.5	24	
018	267175-0	FLAT WASHER 24	1	
019	234322-8	COMPRESSION SPRING 25	1	
020	267766-7	CUP WASHER 14	1	
021	216011-7	STEEL BALL 5.6	2	
022	227338-0	SPUR GEAR 22	3	
023	326385-9	SPINDLE	1	
024	268311-1	PIN 5	3	
025	253147-1	FLAT WASHER 15	1	
026	266915-3	HEX.SOCKET HEAD BOLT M4X25	4	
027	233910-8	RING SPRING 43	1	
028	227337-2	INTERNAL GEAR 51	1	
029	213785-1	O-RING 49	1	
030	142389-1	INTERNAL GEAR CASE COMPLETE	1	
031	632D62-0	STATOR UNIT	1	
032	619341-9	ROTOR	1	
033	454850-9	REAR COVER	1	
034	266130-9	TAPPING SCREW BIND PT 3X16	2	
036	643850-6	TERMINAL	1	
037	424517-3	CUSHION	1	
038	187821-8	HOUSING SET INC. 1	1	
039	620295-5	LED CIRCUIT	1	
040	142394-8	SWITCH PLATE COMPLETE	1	
A01	266622-8	+ TRUSS HEAD SCREW M4X12	1	
A02	346317-0	HOOK	1	
A03	***DC18RC	DC18RC FAST CHARGER	1	
A04	196064-1	BATTERY BL1430 SET	2	
A05	450128-8	BATTERY COVER	1	
A06	824979-9	PLASTIC CARRYING CASE	1	

SERVICE DRAWING

MODEL NO. DTW280

