

SPARE PARTS LIST

MODEL NO. 6300L

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	192877-8	DRILL CHUCK S13	1	
002	325494-1	SPINDLE	1	
003	254211-1	KEY 5	1	
004	285808-5	BEARING RETAINER 25-36	1	
005	211206-7	BALL BEARING 6202LLB	1	
006	156974-4	GEAR HOUSING INC. 7	1	
007	263002-9	RUBBER PIN 4	1	
008	211016-2	BALL BEARING 626LLB	1	
009	226028-2	GEAR COMPLETE 7-41	1	
010	261008-1	FIBER WASHER 6	1	
011	212012-3	NEEDLE BEARING 609	1	
012	156973-6	GEAR HOUSING COVER INC. 16	1	
013	211031-6	BALL BEARING 608LLB	1	
014	213002-9	DUST SEAL 8	1	
015	411234-4	BAFFLE PLATE	1	
016	263002-9	RUBBER PIN 4	1	
017	212003-4	NEEDLE BEARING 810	1	
018	961054-1	RETAINING RING S-14	1	
019	221261-1	SPUR GEAR 47	1	
020	257018-4	RING 15	1	
021	911276-3	PAN HEAD SCREW M5X55	2	
022	911256-9	PAN HEAD SCREW M5X35	2	
023	951151-1	SPRING PIN 5-12	1	
024	241015-0	FAN 68	1	
025	512638-4	ARMATURE ASS'Y 220V	1	
026	911275-5	PAN HEAD SCREW M5X50	2	
027	681613-2	INSULATION WASHER	1	
028	263014-2	RUBBER PIN 4	1	
029	211031-6	BALL BEARING 608LLB	1	
030	253192-6	FLAT WASHER 14	1	
031	522265-9	FIELD ASS'Y 220V	1	
032	953106-2	RIVET 0-5	2	
033	811809-3	NAME PLATE 6300L	1	
034	643550-8	BRUSH HOLDER CAP 5-8	2	
035	181021-2	CARBON BRUSH CB-51	1	
036	159087-0	MOTOR HOUSING INC. 28	1	
037	651235-2	SWITCH C2M-A1T	1	
039	419512-6	HANDLE COVER	1	
040	911153-9	PAN HEAD SCREW M4X28	4	
041	645208-5	NOISE SUPPRESSOR	1	115/220V
042	911133-5	PAN HEAD SCREW M4X18	2	
043	687002-9	STRAIN RELIEF	1	
044	682504-0	CORD GUARD 10-85	1	
045	665016-8	POWER SUPPLY CORD 1.00-2-2.5	1	
046	646328-8	LINE COIL	1	
410	256828-6	ROD 8	1	
411	924306-1	WING BOLT M6X10	1	
412	164187-3	STOPPER HOLDER	1	
413	152892-4	GRIP COMPLETE	1	
414	763432-9	CHUCK KEY S13	1	
415	410102-8	KEY HOLDER	1	
416	286210-5	CAP 20	1	

SERVICE DRAWING

MODEL NO. 6300L

