

SPARE PARTS LIST

MODEL NO. BUM166

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	915116-7	BINDING HEAD SCREW M4X12	1	
002	140599-4	PROTECTOR COMPLETE	1	
003	187427-2	HOUSING SET INC. 27	1	
005	643854-8	TERMINAL	1	
006	452438-9	LOCK OFF BUTTON	1	
007	231473-8	COMPRESSION SPRING 4	1	
009	620117-9	CONTROLLER	1	
010	451812-8	LOCK LEVER	1	
011	651891-8	SWITCH V-15-3A6	1	
012	231473-8	COMPRESSION SPRING 4	1	
013	417564-1	SWITCH LEVER	1	
016	451814-4	DUST GUARD	1	
017	268254-7	PIN 6	1	
018	261122-3	WASHER 6	1	
019	268256-3	PIN 4	2	
020	227728-7	HELICAL GEAR 47	1	
021	165609-6	CRANK COMPLETE	1	
022	629941-7	DC MOTOR	1	
023	268076-5	PIN 6	1	
024	261122-3	WASHER 6	1	
025	226831-1	GEAR 12-31	1	
026	261122-3	WASHER 6	1	
027	187427-2	HOUSING SET INC. 3	1	
028	266429-2	TAPPING SCREW 3X16	6	
029	896921-0	BUM166 NAME PLATE	1	
030	195267-4	SHEAR BLADE ASSEMBLY SET	1	
031	140451-6	UNDER COVER COMPLETE	1	
A01	326146-7	BASE FRAME	1	
A02	451813-6	CHANGE LEVER	1	
A03	452055-5	BLADE COVER	1	

SERVICE DRAWING

MODEL NO. BUM166

